





## GLASS WASH MACHINE DETERGENT

**Glass Wash Machine Detergent is a highly concentrated low foaming and self-drying detergent especially formulated for washing glasses and cutlery in automatic dishwashing and glass washing units.**

Glass Wash Machine Detergent contains an anti-crazing agent to help keep your glasses from clouding, saving time on polishing. Glass Wash Machine Detergent is safe on all types of glass and ceramics and offers economical in use costs for bars, restaurants, pubs and clubs or any facilities where high volume glass washing occurs.



### FEATURES & BENEFITS

-  Concentrated formula for economical use
-  Streak Free results
-  Reduced drying times
-  Promotes better results – less time polishing

### DIRECTIONS FOR USE

For best results use in- conjunction with an automatic dispenser. If the machine is not equipped with a unit the product may be added to Wash tank or used in Rinse Aid Reservoir in dishwashers.

Ensure that the wash tank is emptied and cleaned at the end of each shift.

Not to be used for any other purpose. Do not mix with other chemicals.

### FIRST AID & SAFETY

Considered a hazardous product. Avoid contact with skin and eyes. Wear gloves and eye protection when handling. Keep out of reach of children. If swallowed seek medical advice. If swallowed do NOT induce vomiting, give water. If skin contact occurs wash affected area and remove clothing. If in eyes, hold eyes open and flush with water for a minimum of 15 minutes. Call a Doctor if irritation occurs. Refer to Safety Data Sheet for more information.



### PACK SIZES

Size	Code
5L	NCGWMD5
20L	NCGWMD20

